SPYTEC

Wall Switch Hidden Camera

Quick start guide

www.spytecinc.com

Getting Started with Your Camera

1. Remove the face plate off the device.
2. Insert your Micro SD card into the slot located next to the USB port with the gold contacts facing down.
3. Connect the USB cord to your PC or Mac to charge device. When the device is charging, the blue light will stay solid with a yellow flashing light. Once fully charged the blue and yellow light will be solid.
4. Consult the user manual to find the visual diagram of the device's buttons. Look for "The Key to Open" button. Once you have found the button, press and hold the button for 2 seconds. A blue/yellow light will turn on and after a second, the yellow light turns off. The device will be in standby mode.

Note: For the rest of the guide, please refer to the visual diagram in the manual for help with finding button locations.

Using the Video Recording Feature

1. While the camera is in standby mode, press the "The Key to Open" button for once and release. The blue light will flash 3 times and shut off. The recording will now start.
2. To stop recording, press the "The Key to Open" button once the blue light will flash twice and stay solid. The device is now back in standby mode.

Using the Motion Detection Feature

1. While the device is in standby, put the Mode Switch to the right. The yellow light will flash twice and turn off. If the device detect any motion the yellow light will flash twice.
2. To stop motion recording, put the Mode Switch to the left. The blue light will flash twice and stay solid. The device is now back in standby mode.

Using the Voice Recording Feature

1. While the camera is in standby mode, press the “Voice Key” button for once and release. The blue/yellow light will flash 2 times and shut off. The recording will now start.
2. To stop recording, press the “Voice Key” button once the blue light will flash twice and stay solid. The device is now back in standby mode.

View Videos on a PC or Mac

1. On a PC

a. Plug Wall Switch Camera into a USB port.
b. Double-click on “My Computer” and locate “Removable Disk”.
c. Double-click on “Removable Disk”.
d. Double-click on “DCIM”.
e. Double-click on “100DSCIM”.
f. You may now copy, move, or play your video files.

2. On a Mac

a. Plug Wall Switch Camera into a USB port.
b. The Flash Drive will be recognized as an External Hard Drive.
c. Double-click on the External Hard Drive.
d. Double-click on “DCIM”.
e. Double-click on “100DSCIM”.
f. You may now copy, move, or play your video files.

Wall Switch Hidden Camera

Quick start guide

SPYTEC

www.spytecinc.com